


# Dynamic Enable Query

When processing Assemblies for *Dynamic Enabling*, a Query Definition is used to identify all sub-assemblies and sub-sub-assemblies and so on. The default **View3D\_DynamicallyEnablingCAD** Query Definition is used for this purpose. The query uses the 'Exists' Aggregate Function in the Where Condition applied to the CAD Structure, along with added Query Items that will identify the existence of related CAD Structures and CAD Items. The result will only process CAD Items in the CAD Structure hierarchy that are Assemblies – it ignores Component CAD Items. This is because the Dynamic Viewer only applies to Assemblies.



## Important

Federated Properties cannot be used in Where clauses for a Query Definition.

